


Concrete Design with SCIA Engineer



Official Partner of SCIA in Cyprus

Process for calculation

1. New > Select New Project > Analysis > OK
2. Project data > Basic data > Material (Concrete)
 - > Functionality > Dynamics > Seismic
 - > Stability
 - > Subsoil (Soil Interaction, Pad foundation check)
 - > Property modifiers
 - > Structural model
3. Setup > Mesh
4. Setup > Solver
5. Setup > Concrete solver
6. Main > Structure > Modelling/Drawing > Import DWG, DXF, VRML97 or
Main > Line grid and storeys > 3D Line grid or File > Import > IFC 2x3
7. Storeys
8. Cross-sections
9. Main > Structure > 1D member
 - > 2D member
10. Connect Members/nodes
11. Layers (Για όλες τις διατομές και πλάκες ανά όροφο)
12. Main > Structure > Model data > Section on beam
13. Connect Members/nodes
14. Main > Structure > Model data > Support > surface (el. foundation)
15. Main > Structure > Model data > Property Modifiers 1D (0.5)
 - For 1D members below ground ($0 <$) change "Mass factor" to 0*.
16. Main > Structure > Model data > Property Modifiers 2D (0.5)
 - For 2D members below ground ($0 <$) change "Mass factor" to 0*.
- * "Mass factor" has to be zero (0) because foundations and basements have no movement because according to codes they are non-sway members.
17. Connect Members/nodes
18. Check structure data
19. Main > Load Cases (Selfweight, Dead, Dead-Partitions, Dead-Roof, Live)

Official Partner of SCIA in Cyprus



Evgeniou Voulgareos 87A, 4153, Limassol,
Cyprus
Tel: +357 25251718, Mob: +357 97614727
Email: info@masesoftware.com



20. Main > Load Groups (Permanent, Dead-Partitions, Dead-Roof, Variable)
21. Main > Loads > Dead > Surface load > on 2D member
 - > Live > Surface load > on 2D member
 - > Dead-Partitions > Line force > on 2D member edge
22. Mesh generation
23. Main > Dynamics > Mass groups (Selfweight, Dead, Live)
24. Main > Dynamics > Combination of mass groups (Add All > OK)
 - > For "Dead" and "Live" loads below surface (also with ground floor) are NOT added to the "Combination of mass groups" because masses bellow ground surface are NOT calculated.
 - > For "Live" loads for seismic combination above ground (0+) > Used Coeff. = 0.3 (Auto)
 - > Code: $\Psi_{Ei} = \varphi \times \psi_{2i} = 0.3$ (Residential $\varphi = 1$, $\psi_2 = 0.3$) - Table A1.1 + A1.2(B) (CYS)
25. Libraries > Loads > Seismic spectrums
 - > Period
 - > Eurocode
 - > Code parameters > $AgR^* \gamma_i$, q factor, Subsoil, Spectrum (Type 1), Direction.
26. Main > Load Groups (Together, Seismic)
27. Main > Load Cases (Seismic > Dynamic > Seismicity > CQC)
 - > Seismic X => X=1, Y=0, Z=0
 - > Seismic Y => X=0, Y=1, Z=0
28. Main > Combinations (ULS B, ULS C, SLS, Seismic X (0.3Y), Seismic Y (0.3X)).

At "Seismic" Combinations do NOT add ground floor or basement "Dead" or "Live" loads.
29. Main > Stability combinations (Selfweight, Dead, Live)
30. Main > Result classes > TOTAL (ULS, Seismicity)
 - > DYN (Seismicity)
 - > GEO (ULS Set B, ULS Set C)
 - > SERV (SLS-Char, SLS-Quasi)
31. Calculation > Modal
32. Main > Results (Modal Participation factors W_{xi} , W_{yi} , $W_{zi_R} \geq 0.90$)
33. Main > Load Cases (Predominant mode > Automatic > Mode shape for W_{xi} , W_{yi})

Official Partner of SCIA in Cyprus



Evgeniou Voulgareos 87A, 4153, Limassol,
Cyprus
Tel: +357 25251718, Mob: +357 97614727
Email: info@masesoft.com



34. Calculation > Test of input data (Δημιουργεί τις σωστές μάζες ανά μέλος που έχει Line force) Το ίδιο γίνεται και με το "Mesh generation".
35. Calculation > Batch analysis (Linear, Modal, Stability)
 - Solver setup > [Use IRS in case of 2 storeys or more](#)
36. Main > Results
37. View > New animation window > Play
38. Calculation > Batch analysis (Linear, Modal, Stability)
39. Main > Concrete > Design defaults
40. Main > Concrete > 1D member
 - > Member buckling data
 - > Concrete slenderness
41. Main > Results > Beams > Internal forces on beam
 - If beams are Ribs > Properties > Rib/Integration strip (√)
42. Main > Results > 2D member
43. Main > Results > 2D member > Integration strip (Strip foundation)
44. Main > Concrete Advanced > 2D member > Member design > Member design ULS
 - > Properties > Use scale isolines
45. Main > Concrete > 1D member Member check
 - > Check of non-prestressed concrete
 - > Overall check
 - > Check response
 - > Check capacity
 - > Check deflection
46. Main > Concrete > 1D member > Member design - Design
47. Main > Concrete > 1D member > AMRD > Member design - Design
 - > Reinforcement design or
 - > Redes (without As)
48. Main > Concrete > 2D member > Reinforcement 2D
49. Engineering Report for concrete results

Για την γεωμετρία θα χρειαστεί να ενεργοποιήσετε:

- Snap mode  ή Snap mode
- View > Set view parameters > Set view parameters for all

Official Partner of SCiA in Cyprus

Ακόμη και αν εισάγατε αρχείο CAD στον κάρναβο σας προτιμότερο θα ήταν να δημιουργήσετε και κάρναβο "3D line grid".

Official Partner of SCiA in Cyprus



Evgeniou Voulgareos 87A, 4153, Limassol,
Cyprus
Tel: +357 25251718, Mob: +357 97614727
Email: info@masesoft.com



Concrete foundation

50. Remove supports
51. Main > Structure > 2D member (Wall=Shell, Slab=Plate)
52. Main > Structure > Model data > Support > surface (el. foundation)
53. Main > Structure > Model data > Property Modifiers 1D (0.5)
For 1D members below ground (0 <) change "Mass factor" to 0*.
54. Main > Structure > Model data > Property Modifiers 2D (0.5)
For 2D members below ground (0<) change "Mass factor" to 0*.
* "Mass factor" has to be zero (0) because foundations and basements have no movement because according to codes they are non-sway members.
55. Libraries > Load > Seismic spectrums (q-factor for concrete)
56. Connect Members/nodes
57. Check structure data
58. Analysis > Batch analysis (Linear, Modal, Stability)
59. Main > Results > Beams > Internal forces on beam
> Properties > Rib/Integration strip (√)
60. Main > Results > 2D member
61. Main > Results > 2D member > Integration strip (Strip foundation)
62. Main > Concrete > 2D member > Member design > Member design ULS
Properties > Use scale isolines
63. Main > Concrete > 2D member > Reinforcement 2D
64. Connect Members/nodes
65. Check structure data
66. Analysis > Test of input data
67. Analysis > Batch analysis (Linear, Modal, Stability)
68. Main > Results
69. Engineering Report for steel results
70. Engineering Report for concrete results

Για την γεωμετρία θα χρειαστεί να ενεργοποιήσετε:

- Snap mode  ή
- View > Set view parameters > Set view parameters for all

Ακόμη και αν εισάγατε αρχείο CAD στον κάρναβο σας προτιμότερο θα ήταν να δημιουργήσετε και κάρναβο "3D line grid".

Official Partner of SCIA in Cyprus



Evgeniou Voulgareos 87A, 4153, Limassol,
Cyprus
Tel: +357 25251718, Mob: +357 97614727
Email: info@masesoft.com

